

## Operation

The heating function of your Heated Gloves can be controlled by a switch integrated in the USB cable.  
The heating function is adjustable in two levels (I = low, II = high).



We hope you enjoy working with the Heated Gloves.



Comfortable Computing • Manuel Machajdik  
Amraser Str. 119 • A-6020 Innsbruck

Tel & Fax: +49 (0)12120 230444  
Tel: +43 (0)699 31334663

info@comfortable-computing.com  
[www.comfortable-computing.com](http://www.comfortable-computing.com)



## Heated Gloves

with USB connector



Item **HM-07-02**

**User's Manual**

## Thank you!

Thank you for purchasing a pair of Heated Gloves from Comfortable Computing. All our products are manufactured with great care and individually tested. If you still have any reason for an objection, please contact us. Together we will find a solution!

## Security Advice

Please note the following indications in order to assure safe operation.

- This is not a toy! Keep out of the reach of children.
- Never leave the heating function on without surveillance.
- Never leave the heating function on continuously for a long period of time, e.g. overnight.
- Never tip any fluids on the gloves and never expose the gloves to high humidity.
- Do not expose the gloves to extreme high or low temperature or direct sunlight.
- Switch off the heating function immediately and contact customer service, if there is any smoke or smell coming out of the gloves.


## Technical Specifications

- Two heating elements for wrist and fingers
- Heating up to 50°C (120 °F)
- Heating function switchable on/off
- USB 1.1 connector

## Product Contents

- 1 pair of Heated Gloves
- 2 USB connectors with switch
- User's Manual

## Your Heated Gloves



## Installation and Driver

The Heated Gloves do not need a device driver. The Heated Gloves work with every operating system (Windows, Linux, MacOS) on all USB capable devices (including Playstation and XBOX 360).

Just plug the USB connector of the gloves into a free USB port (not on a USB-Hub) and switch to the desired heating intensity.

